

NOTE: 3913 Series Pick Up Pack shown with optional Lumber Rack, Rebar Boxes, Cab Guard and Gull Wing Saddle Box. Other configurations will vary slightly, but will not affect assembly.

Attention Read all instructions and understand all warnings before installing or using this product.



Danger

Danger of Explosion

This product was not intended for the use of storing or transporting flammables, explosives, hazardous materials and hazardous waste such as but not limited to: gasoline, gun powder, dynamite, solvents or any pressurized tanks. Doing so could create hazardous conditions that can cause death, serious injury or property damage.



Danger

Notes

- Use safety glasses when using tools or working under vehicle.
- Perform all work on dry level ground.
- Insure vehicle's parking break is engaged and wheels are chocked.
- Due to the size and weight of products, more than one person is required for lifting and installing this product.
- For wiring: black wire is positive (+) and white wire is negative (-)



Tools Required

	SAFETY GLASSES		RATCHET SET
	MARKING PEN		WRENCH
	DRILL & BIT SET		CLAMPS
	TAPE MEASURE		RUBBER MALLET




STEP 1.1:

Adhere provided 4" rubber weather stripping along the bottom of Pick Up Pack as shown in Figure 1.1.

Note:
Front Weather Stripping may require to be doubled up depending contour of front and side bed rail.

Figure 1.1

Weather Stripping
(Remove protective film
adhere this side)



APPROX.
1" - 1-1/2"
SPACING

EQUAL

STEP 1.2:

Place Pick Up Pack on truck bed.
Adjust Pick Up Pack centered
(left to right) on the cab of truck
as shown in Figure 1.2.




Figure 1.2



STEP 2.1:

Apply Aluminum Bracket and D-Section Weather Strip to back of Low Side Box as shown in Figures 2.1 & 2.2.




Figure 2.1




Figure 2.2

STEP 2.2:

Adjust Pick Up Pack (front to back) pulling the Pick Up Pack towards back of truck so D-Section Weather Strips are touching back of tailgate creating a seal as shown in Figures 2.3 & 2.4.




Figure 2.3




Figure 2.4



STEP 3.1:

Maintain equal distance of _____" along inside of Pick Up Pack during Step 3.2 to ensure proper operation of Boxes and Hatch. See Figure 3.1 for distance. Measure height of Low Side Boxes are equal to bed and are level.


NOTE: Check operation of Hatch and Tailgate prior to Step 3.2.

STEP 3.2:

Drill two $\phi 1/4$ " holes through the ledge of each Low Side Box (front and back of box). Do not drill through top of Truck Bed Rail as shown in Figures 3.1 & 3.2.

Note : When using self tapping screw , ensure hole for fastening is through metal on the truck Bed Rail, giving the fastener a secure place to hold down the Pick Up Pack.

Figure 3.1



DRILL $\phi 1/4$ " THRU LOW SIDE BOX LEDGE ONLY

DRILL $\phi 1/4$ " THRU LOW SIDE BOX LEDGE ONLY




Figure 3.2

DRILL $\phi 1/4$ " THRU LOW SIDE BOX ONLY


Figure 3.3



STEP 4.1:


Fasten Low Side Box to Bed Rail through 1/4" holes drilled in previous step to Bed Rail as shown in Figure 4.1

Screw #14 x 1-1/2" Tek Self Tapping
Washer Fender 1/4" x 1-1/2"



GENERAL LOCATION OF MOUNT BRACKET AT REAR OF LOW SIDE BOX

Figure 4.1



(DS Back Section) Figure 4.2

Nut Zinc 5/16"-18 Revlock
Washer Zinc 5/16" Flat SAE
Bottom Mounting Bracket
Top Mounting Bracket
Washer Zinc 5/16" Flat SAE
Bolt Zinc 5/16"-18 x 1" Hex Bolt
Screw #14 x 1-1/2" Tek Self Tapping

SKIP TO STEP 6.1 IF PICK UP PACK HAS REBAR BOXES INSTALLED

STEP 4.2:

At the rear of Low Side Box (see Figure 3.1), Fasten Bottom Mounting Bracket to side of Bed Rail. Adjust and tighten Top Mount Bracket under Low Side Box. Match Drill through Bottom of Low Side Box and fasten as shown in Figure 4.2



**SKIP STEP IF PICK UP PACK
DOES NOT INCLUDE GULL WING SADDLE BOX**




Figure 5.1

STEP 5:

**Open Gull Wing Saddle Box fasten
to Bed Rail as shown in Figures 5.1 & 5.2.**

Note:

Additional fastening hardware in this step,
Part# 570-00022, is included with
Gull Wing Saddle Box.




Figure 5.2



REBAR BOX INSTALLATION

STEP 6.1:

Align the front face of Rebar Box Spacer and open side of Rebar Box, mark and drill 3/8" hole. fasten Rebar Box Spacer and Rebar Box as shown in Figures 6.1 & 6.2.

NOTE:

Driver Side installation shown.





Figure 6.1

STEP 6.2:

Ensuring bottoms of Low Side Boxes are at Equal heights and constant width the length of boxes (See Figure 3.1 & 6.3).

Align Rebar Box Spacer with outside of the Low Side Box. Ensure Rebar Box's open face is not obstructed by Truck Bed. Mark and drill 3/8" hole in to Low Side Box as shown in Figure 6.3.

NOTE:

Driver Side installation shown.




Figure 6.3



STEP 7:

Fasten Rebar Box to Low Side Box and Truck Bed as shown in Figure 7.




Figure 7